

# **Petro 3003**

## **Lühikasutusjuhend**

### **VOLUTANK**

(Ilma SAFE, koos täisvoolikuga, koos entresteniga, koos ettevõtte valikul)

Tarkvara versioon PYRAMIDE 2.5.x

KBA 210338


**PLEASE NOTE**

*This document is a short version of the product operation. It must be kept in the immediate vicinity of the device so that access to it is possible at any time.*


*To be observed safety and more detailed instructions, see the operation manual.*

*The current version can be downloaded from [www.bartec.de](http://www.bartec.de) or requested from BARTEC BENKE GmbH.*


# Laaditud ilma SAFE`ita




# Laaditud koos ettevõtte valikul




Kambri täitmine




Kamber täidetud



2. Laadimismenüüst lahkumine







Kambrite valimine



1. Põhjaveentide sulgemine


Toote rühmitamine




# Väljastamine ilma SAFE´ita




# Täisvooliku (tankimispüstol voolikuga) paralleelne väljastus



# Täisvooliku (tankimispüstol voolikuga) järjestikune väljastus




# Täisvooliku (tankimispüstol voolikuga) osaline väljastus





# Eemaldada jäägid kogurist



# Ülevaade töörežiimide näidikust

